

## Operating the H82 Speaker

The speaker timer helps to keep presentation-times to the schedule by displaying a countdown to the moderator and speaker. The moderator controls the countdown and the speaker is informed about the remaining time for the presentation. This is accomplished by two tablets that are wirelessly connected.

Usually the “Master unit” is located at the moderator table and the “Slave unit” at the lectern.

### 1. Initial adjustment

- To adjust the presentation-time, press +1, +5, -1 or -5. Be sure that the device is stopped before doing that. The “Time Limit” indication at the top always displays the complete speaking time, while the big time indication in the middle displays the remaining time for the presentation.




### 2. Play / Pause / Stop

- Press the green PLAY button to start the countdown (at beginning of presentation)
- Press the yellow PAUSE button to pause the countdown – this button appears during countdown only
- Press the red STOP button to stop the countdown and to reset the display to the initial value.

The actions immediately become visible on the speaker’s device.

### 3. Colors

- Color-changement of the digits remind the speaker of the remaining time.



### 4. Adjust during presentation

- Time setting can also be adjusted during the countdown running by pressing +1, +5, -1 or -5, to increase or decrease the remaining presentation-time.

### 5. Tips & Hints

- Depending on the type and rules of sessions it might be useful to dedicate some minutes of the presentation timeslot to Q & A (for example 15 minutes slot for presentation = 12 minutes presentationtime plus 3 minutes Q & A).